
INSTRUCTION MANUAL

MECHANICAL LIFT TABLE



MST 300

MAX: 300 KG

1. Brief Instruction

1. Use & applicable range

It is a convertible vehicle using for lifting and transporting in workshop, warehouse and wharf, etc. Its rated capacity is 300kgs.

2. Characteristics:

- I. Use wave the handle to lift the table, and the table's height is fixed, which can avoid the auto-lowering down like the hydraulic device.
- II. Push to make the four wheels running and move the cart by hand.

3. Basic Data:


Load capacity:	300kg/660lb
Maximum Height of Table:	1000mm
Minimum Height of Table:	440mm
Dimension of Table:	950×600mm
Net Weight:	60kg

4. Operation

Firstly, fix the table by the brake in the swivel wheel holder. Wave the handle to lift up and lower down the table.

5. Warning!

- I. Operate strictly according to the instruction manual.
 - II. Do not use the cart on slop.
 - III. Do not overload the goods.
 - IV. Keep feet and hand away from under the lowering table.
 - V. Locked the swivel wheel holder before you lift and lower down the table.
-



MST300 MECHANICAL LIFT TABLE

No.	Description	Quantity
1	Table	1
2	Frame 1	1
3	Lopck Nut	2
4	Washer	2
5	Spacer Bush	2
6	Spacer Bush	1
7	Screw Rod	2
8	Bearing	1
9	Set Nut	2
10	Flat Washer	2
11	Spring washer	2
12	Screw	2
13	Handle	2
14	Bush	1
15	Screw	1
16	Frame 2	1
17	Ring	12
18	wheel	2
19	Pin	2
20	Chassis	1
21	Lock Nut	2
22	Flat Washer	2
23	Aegis Cover	2
24	Screw	2
25	Spacer Bush	2
26	Spacer Bush	4
27	Bearing	4
28	Roller	4
29	Pin	4
30	Swivel Caster	2
31	Flat Washer	8
32	Spring washer	8
