User manual for tilting skips

Step 1.

Step 2.

Step 3. Empty the skip automatically (left picture) or manually (right picture)